



# TANK SELECTION FOR CONSTANT PRESSURE

AMTROL'R PRESSURE SETTING (Cut-In/Cut-Out)				
	30/40	40/50	50/60	60/70
5	WX-205	WX-205	WX-250	WX-250
7	WX-250	WX-251	WX-251	WX-251
10	WX-251	WX-255	WX-255	WX-302
12	WX-350	(2) WX-255	(2) WX-302	(2) WX-350
15	(2) WX-302	(2) WX-302	(2) WX-350	(2) WX-350

*\*5-10 GPM pump sizing up to 1hp. 12 & 15 GPM to 2hp.*

*For applications not listed, call AMTROL® Tech Support  
(401) 535-1216 or visit [www.amtrol.com](http://www.amtrol.com)*

# **AMTROL'R™ TROUBLESHOOTING**

<b>CODE</b>	<b>REASON</b>	<b>SOLUTION*</b>
<b>E1</b>	Rapid Cycle	Check pressure tank size Inspect for waterlogged tank
<b>E2</b>	Low Suction	Check well level Ensure jet pump is primed Inspect for loose wiring
<b>E3</b>	Voltage Fault	Restore proper voltage
<b>E4</b>	Pump Over Temp	Allow pump to cool, determine cause
<b>E5</b>	Improper Wiring	Check LINE/MOTOR connections

\*See installation manual for detailed troubleshooting.

*After correcting problem, press and hold all three buttons simultaneously until unit resets.*